

639/640 Strike Installation Instructions for Concealed Vertical Rod Exit Device with AD- Option

SARGENT
ASSA ABLOY



1) Prepare frame
(Pair of doors shown; for
detailed strike preparation
refer to template # 4649)



2) Slide strike
into frame



3) Position strike
so screw holes
are aligned



4) Hold strike &
secure with screw



5) Secure with
2nd screw



6) Repeat process
for 2nd strike

Note: Perform the same steps for threshold strike(s)