

TEMPLATE INSTRUCTIONS

(For Light-Duty Escutcheon Lever Trim Use)

For backset, see page 1
of installation instructions
for details on
DOOR APPLICATIONS

For backset, see page 1
of installation instructions
for details on
DOOR APPLICATIONS

TRIM MOUNTING HOLES X2
DRILL $\varnothing 7/16"$ (11mm) HOLE ON
OUTSIDE FACE OF DOOR

TRIM ACTUATING SHAFT HOLE
DRILL $\varnothing 1/2"$ (13mm) THROUGH HOLE

TRIM \varnothing
CORRESPONDS TO EXIT DEVICE \varnothing

2-7/8"
[73mm]

EDGE OF DOOR

2-7/8"
[73mm]

TRIM MOUNTING HOLES X2
DRILL $\varnothing 7/16"$ (11mm) HOLE
ON OUTSIDE FACE OF DOOR

TRIM ACTUATING SHAFT HOLE
DRILL $\varnothing 1/2"$ (13mm) THROUGH HOLE

TRIM \varnothing
CORRESPONDS TO EXIT DEVICE \varnothing

LHR

RHR

OUTSIDE FACE OF DOOR

OUTSIDE FACE OF DOOR

