



**-ADDENDUM-
SAM2 STRIKE ASSEMBLY
INSTALLATION TEMPLATE**

***FOR HARD CORE WOOD TYPE DOOR**

*THIS TEMPLATE IS TO BE USED IN PLACE OF THE
HARD CORE WOOD TYPE DOOR TEMPLATE SHOWN ON
SHEET 2 OF 3 OF THE SAM2 TEMPLATE (P/N 500-20240)
UNTIL FURTHER NOTICE.

SECURITRON
ASSA ABLOY

P/N 500-20241-A
(SHEET 1 OF 1)