

DEPTHS			SPACES			FORE	ANGLE DIRECTION	AFT												
#	INCH	MM	#	INCH	MM															
0			1 FORE	.213	5.41	K	(LEFT)	M												
1	.272	6.90	1 AFT	.275	6.99	B	(CENTER)	D												
2	.247	6.27	2 FORE	.383	9.73	Q	(RIGHT)	S												
3	.222	5.64	2 AFT	.445	11.30	TIP SIDE														
4	.197	5.00	3 FORE	.553	14.05	K M B D Q S														
5	.172	4.37	3 AFT	.615	15.62	K	3	4	3	4	3	4								
6	.147	3.73	4 FORE	.723	18.36	M	2	3	2	3	2	3								
7			4 AFT	.785	19.94	B	3	4	3	4	3	4								
8			5 FORE	.893	22.68	D	2	3	2	3	2	3								
9			5 AFT	.955	24.26	Q	3	4	3	4	3	4								
10			6 FORE	1.063	27.00	S	2	3	2	3	2	3								
11			6 AFT	1.125	28.58	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>DEPTH INCREMENT</p> <table border="1"> <tr> <th>INCH</th> <th>MM</th> </tr> <tr> <td>.025</td> <td>.635</td> </tr> </table> </div> <div style="width: 45%;"> <p>SPACE INCREMENT</p> <table border="1"> <tr> <th>INCH</th> <th>MM</th> </tr> <tr> <td>*.170</td> <td>4.318</td> </tr> </table> </div> </div>							INCH	MM	.025	.635	INCH	MM	*.170	4.318
INCH	MM																			
.025	.635																			
INCH	MM																			
*.170	4.318																			
						<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> </div> <div style="width: 45%;"> <p>* NOTE: SPACING IS CRITICAL!!</p> <p>MAKE SURE YOUR MACHINE IS PROPERLY ADJUSTED!!</p> </div> </div>														

## MEDECO BIAxIAL