

NOTE: 1. DO NOT REMOVE POWER WHILE IN THE PROGRAM MODE.
2. LOCATIONS B11 THROUGH B17 MAY BE ACCESSSED IN USER-PROGRAM MODE

ARM/DISARM CODE 1	B11
ARM/DISARM CODE 2	B12
ARM/DISARM CODE 3	B13
ARM/DISARM CODE 4	B14

ENTRY DELAY TIME	B15
X10 SECONDS	
EXIT DELAY TIME	B16
X10 SECONDS	
ENABLE ONE-BUTTON	B17
ARMING	1
ENABLE 10-SECOND	B17
PSC-ALARM	2

FEATURE	1	2	3	4	5	6	NO	LOW	CLO	CLO	OPEN	BY USER	
REPORT OR ALARM	B20	B20	B20	B20	B20	B20	AC	BAT	OPEN	1	2	3	4
REPORT ON RESTORE	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
DAY ZONE	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
PRIORITY	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
AUTO-BYPASS	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
SELECTIVE BYPASS	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
GROUP BYPASS	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
24-HOUR ZONE	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
AUTO-RESET	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
ABORT DELAY	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
ALARM OUTPUT	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
10-SEC LOOP RESPONSE*	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
50-SEC LOOP RESPONSE*	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
NOT USED (DO NOT PROGRAM)	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
DOUBLE REPORTING	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
OPENING REPORT AFTER ALARM	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
ENABLE KEYPAD PANIC ON ZONE 5	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20	B20
LINE SEIZURE TIME	B25												
X1 SECONDS	(2)												
ANTI-JAM TIME	B26												
X5 SECONDS	(3)												
REDIAL DELAY TIME	B27												
X1 SECONDS	(4)												
WAIT FOR HANDSHAKE	B28												
X5 SECONDS	(7)												
REDIAL ATTEMPTS	B29												
X1	(8)												

NOTE: NUMBERS IN PARENTHESES INDICATE RECOMMENDED PROGRAMMING.
THESE LOCATIONS MUST BE PROGRAMMED FOR COMMUNICATION.

KEYPAD PROGRAMMING RECORD SHEET FOR THE ALCO-4 Communicator Transmission Information

ALARM/TROUBLE CODES

ZONE						NO. L.D.
1	2	3	4	5	6	AC/BAT
B21	B22	B23	B24	B25	B26	B27

Single Digit →
Extended/Two Digit →

RESTORE CODES

B31	B32	B33	B34	B35	B36	B37
-----	-----	-----	-----	-----	-----	-----

Single Digit →
Extended/Two Digit →

OPENING/CLOSING CODES

Closing	Force	Opening	* Must be programmed if Closings are reported.
B43	B44	B45	

Single Digit →

SUBSCRIBER I.D. NUMBERS

Telephone #1	Telephone #2
Alarm I.D.	Alarm I.D.
B51	B52

Format	Pre-UIB	Access	UIB-Tone	Telephone Number
Delay	Number	Detection		
Telephone 1	B57			B58
Telephone 2 (Must be programmed)	B59			B60

ENTRY RECEIVER FORMAT

(Blank)	ADHOC "SLOW"
1	RADIONCS "SLOW"***
2	SESCOA***
3	RADIONCS "FAST"***
4	SLUENZ UNIDIT-7267

*** These formats typically use a 2300Hz Handshake.

ENTRY DATA FORMAT

(Blank)	EXTENDED OR SINGLE DIGIT
1	SINGLE DIGIT
2	TWO DIGIT (OR 4/2)
4	SUM CHECK
8	FOR 2300HZ HANDSHAKE, ADD "8" TO THIS LOCATION