



**Notes:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Dimensions are in inches (mm).
3. LHR door shown. (RHR opposite)
4. For door reinforcement see template T30800.
5. Prepare mounting holes when installing trim.
6. Provide adequate internal support to prevent door deformation after trim is bolted to the device.
7. Dimensions given about a centerline are symmetrical.
8. Unspecified radius 1/8 maximum.
9. Provide 1/2 (13) Dia. raceway for wire harness from inside door face at Hole "A" to top of trim cutout on outside door face. Wire harness shall be free to run thru interior of door without obstructions.



9800/9M800 TCNE Series

Note: Lever design prefix does not affect door prep.



**Access 800® TCNE Series Trim**  
**9803, 9805, 9810 & 9830 SecureBolt and Rim**  
**9M803, 9M805, 9M810 & 9M830 Mortise**  
**for ED5000N Series Exit Devices**  
**Metal Door Preparation**

**Corbin Russwin®**

**ASSA ABLOY**

SUPERSEDES  
TEMPLATE NUMBER

DO NOT SCALE DRAWING

**T31002**

DATE **9-07**