




## Notes:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Dimensions are in inches (mm).
3. LHR door shown. (RHR opposite)
4. Provide adequate structural support to maintain door integrity during operation.
5. Prepare mounting holes when installing trim.
6. Dimensions given about a centerline are symmetrical.
7. Unspecified radius 1/8 maximum.
8. Provide 1/2 (13) Dia. raceway for wire harness from inside door face at Hole "A" to top of trim cutout on outside door face. Wire harness shall be free to run thru interior of door without obstructions.



## 9800/9M800 TCNE Series

Note: Lever design prefix does not affect door prep.



## Section X - X

**Access 800® TCNE Series Trim  
9803, 9805, 9810 & 9830 SecureBolt and Rim  
9M803, 9M805, 9M810 & 9M830 Mortise  
for ED5000N Series Exit Devices  
Wood or Composite Door Preparation**

**Corbin Russwin**    
**ACSA APLOY**

**ASSA ABLOY**

SUPERSEDED

DO NOT SCALE DRAWING

TEMPLATE NUMBER

Page 1000

131003 | 9-07